



General Instructions ***(In-line Fan)***

CFT-CPF-CCK-CPA Series



This manual is to assist the engineer to avoid the most common fan problems caused by improper storage, installation, operation and maintenance. **HANDLING AND MAINTENANCE SHOULD ALWAYS BE PERFORMED BY EXPERIENCED AND TRAINED PERSONNEL.**

RECEIVING, HANDLING AND STORAGE

Rough handling during shipment and improper storage can cause damage that is not noticeable until the fan is in operation. This can be avoided with proper storage and handling techniques.

Touch up the scratch coated surfaces during lifting, to prevent corrosion to occur at this area. Store the fan in a clean and dry place, preferably indoor to ensure fan shaft, bearing and fan casing are protected against dust and corrosion. Do not store the fan in a location where it will be subjected to high vibration.

This can cause the internal surface to rub against each other and damage the bearings.

START-UP CHECK LIST

Before putting any fan into initial operation the manufacturer's instruction must be followed. Complete the following checklist to make sure that the fan is ready to run.

- Lock out the primary and all secondary power sources.
- Make sure the foundation or mounting arrangement and the duct connections are adequately designed in accordance with recognized acceptable engineering practices.
- Check and tighten all hold-down (securing) bolts.
- Spin impeller to see whether it rotates freely and is not grossly out of balance.
- Inspect impeller for correct rotation for the fan design.
- Check belt drive alignment, use recommended belt tension.
- Check belt drive for proper sheave selection and make sure they are not reversed.
- Properly secure all safety guards.
- Switch on the electrical supply and allow the fan to reach full speed.

Check carefully for :- (1) Excessive vibration
(2) Unusual noise
(3) Proper amperage and voltage values
(4) Proper belt alignment

If any problem is indicated, SWITCH OFF IMMEDIATELY. Lock out the electrical supply, secure the fan impeller if there is a potential for wind milling. (impeller turning due to a draft through the system).


Check carefully the cause and correct as required.

The fan may now be put into operation but during the first 8 hrs of running, it should be periodically observed and checked for excessive vibration and noise. Check the motor input current and motor temperature to ensure that they do not exceed manufacturer's recommendation. After 8 hrs of operation, the fan should be shut down to check for the following items:

- (1) All set screws and hold-down bolts
- (2) Belt drive alignment
- (3) Belt drive tension
- (4) Bearing housing temperature

* For V-belt drive installation and belt tension, please refer to our general installation guide for Centrifugal Fan (IGB016.0/0600) for more information.

Installation Method



ROUTINE MAINTENANCE

Maintenance should always be performed by experienced and trained personnel. Do not attempt any maintenance on a fan unless the electrical supply has been locked out or tagged out and the impeller has been secured.

Under normal circumstances, handling clean air, the system should require cleaning only about a Year. However, the fan and system should be checked at regular intervals to detect any unusual accumulation.

The fan impeller should be specially checked for build-up of material or dirt which may cause an Imbalance with resulting undue wear on bearings and belt drives. A regular maintenance program should be established as needed to prevent material build-up.

Periodic inspection of the rotating assembly must be made to detect any indication of weakening of the rotor because of corrosion, erosion, or metal fatigue.

THE KRUGER GROUP

SINGAPORE

Kruger Ventilation Industries Pte Ltd

No. 17, Tuas Avenue 10
Singapore 639141
Tel. +65 68611577 – Fax +65 68613577
Email: mktg@krugerasia.com

MALAYSIA

Kruvent Industries (M) Sdn Bhd

Lot 8, Jalan Perusahaan 2 Batu Caves
Industrial Area, 68100 Batu Caves Selangor
Tel. +603 61888293 – Fax +603 61898843
Email: mktg@kruger.com.my

BEIJING

Beijing Kruger Ventilation Co. Ltd

No. 1A South Industry Area
Beijing Economical And Technological
Development Area, Beijing China 100176
Tel. +86 10-67881366 – Fax +86 10-67880566
Email: krugerbj@krugerchina.com

HONG KONG

Kruger Ventilation (Hong Kong) Limited

Flat C, 9/F,
Yeung Yiu Chung (No. 8) Industrial Building,
20 Wang Hoi Road,
Kowloon Bay, Kowloon, Hong Kong
Tel. +852 22469182 – Fax +852 22469187
Email: cfyau@kruger.com.hk

WUHAN

Wuhan Kruger Ventilation Co. Ltd

Xincheng Road 10, South Dongwu Ave,
Dongxihu District, Wuhan, Hubei, P.R.China 430040
Tel. +86 27-83248840 – Fax +86 27-83261886
Email: whkruger@krugerchina.com

PHILIPPINES

Kruger M&E Industries Corporation

FAPIC Compound, E. Rodriguez Ave.
Tunasan, Muntinlupa City, Philippines 1773
Tel. +63 2-8622891-97 – Fax +63 2-8621287
Email: mktg@krugerph.com

INDONESIA

P.T. Kruger Ventilation Indonesia

JL. Teuku Umar No.20
Karawaci – Tangerang 15115, Indonesia
Tel. +62 21-5512288/5513557 – Fax +62 21-5513502
Email: mktg@krugerindo.co.id

KOREA

Neomate Technology & Consulting Co. Ltd

2-1010, Ace High City B/D, Mullae-dong 3-ga
Yeongdeungpo-gu, Seoul, Korea, 150-972
Tel. +82 2-26792052 – Fax +82 2-26792174
Email: neomatetnc@chol.com

DUBAI

Kruger Ventilation Industries, Gulf Branch

Jebel Ali Free Zone Area (JAFZA)
Near Roundabout 8, Warehouse No. RA08FC05
P.O. Box No. 262949
Tel. +971 4-8832017 – Fax +971 4-8832018
Email: johnncs@krugerasia.com

SINGAPORE

Kruger Engineering Pte Ltd

No. 17, Tuas Avenue 10
Singapore 639141
Tel. +65 68631191 – Fax +65 68631151
Email: mktg@krugerasia.com

THAILAND

Kruger Ventilation Ind. (Thailand) Co. Ltd

30/105 Moo 1 Sinsakorn Industrial Estate
Chetsadawithi Road, Khok Kham Mueng,
Sakuthsakorn 74000, Thailand
Tel. +662 1050399 – Fax +662 1050370-2
Email: mktg@kruger.co.th

GUANGZHOU

Guangzhou Kruger Ventilation Co. Ltd

No. 9 Huahui Road, Huashan
Huadu, Guangzhou, P.R. China
Tel. +86 20-86786070 – Fax +86 20-86786001/86786500
Email: gzkruuger@krugerchina.com

SHANGHAI

Shanghai Kruger Ventilation Co. Ltd

No. 500 Yuanguo Road, Anting, Jiading,
Shanghai 201814, P.R. China
Tel. +86 21-69573266 – Fax +86 21-69573296
Email: shkruuger@krugerchina.com

TAIPEI

Kruger Ventilation (Taiwan) Co. Ltd

No. 157, Ping-an Rd, Hengfeng Village,
Dayuan Shiang Taoyuan County 337, Taiwan (ROC)
Tel. +886 3-3859119 – Fax +886 3-3859118
Email: kyyang@krugertwn.com.tw

AUSTRALIA

S&P-Kruger Australia Pty Ltd

2 Cunningham St
Moorebank N.S.W. 2170
Tel. +61 2-98227747 – Fax +61 2-98227757
Email: info@sandpkruger.com.au

INDIA

Kruger Ventilation Industries (India) Pvt Ltd

Kruger Centre, Mumbai-Nasik Highway,
Atgaon, Shahapur, Thane 421304, Maharashtra, India
Tel. +91 9860730999 – Fax +91 2527240075
Email: sales@krugerindia.com

VIETNAM

Kruger Ventilation Industries Pte Ltd

(Vietnam Representative Office)

4th Floor, HHM Office Building, 157-159 Xuan Hong St,
Tan Binh Dist, Hochiminh City, Vietnam
Tel. +84 8-6-2968123 – Fax +84 8-6-2968124
Email: mktg@krugervn.com