

Operation Manual

Ecowatt® Drive K154 Series

DIGITAL INVERTER VFD RANGE



CONTENTS	Page
Transport and Handling/General	3
Specification	4
Modes of Operation for the Packaged Inverter/Fan Range	4
KeyPad	5
Important Information for the Safety of Installers and Users	5
Safety During Installation	6
Mechanical Installation	6
Electrical Installation of the Inverter to an Appropriately Sized Kruger Fan	6
<u>Operation Mode a. Off/On to Installer-defined Speed and Thereafter Manual Speed Adjustment via the Inverter's Integral Keypad</u>	9
<u>Operation Mode b. Off/On and Speed Control by Additional Accessory REB-ECOWATT 0-10V Speed Controller</u>	14
<u>Operation Mode c. Off/On by Additional Remote (wired) OFF/ON Switch</u>	17
Pre Starting-up Checks and Initial Energisation	18
Operating Instructions	21
Troubleshooting	22
EMC Filters	23
Recycling	23
EC Declaration of Conformity	23
Guarantee	24

Thank you for placing your confidence in Kruger by buying this product. It has been manufactured following current technical safety regulations and in compliance with EC standards.

Please read this instruction booklet carefully before installing or starting up the product. It contains important information on personal and user safety measures to be followed while installing, using and carrying out maintenance work on the equipment. Once the product has been installed, please hand this booklet to the end user.

Check that the apparatus is in perfect condition while unpacking. Any fault or damage caused in origin is covered by the Kruger guarantee. Please make sure that the apparatus coincides with the product you have ordered and that the details on the characteristics plate fulfil your requirements.

Transport and Handling

1. The packaging used for this apparatus has been designed to support normal transporting conditions. The apparatus must always be transported in its original packaging as not doing so could deform or damage the product.
2. The product should be stored in a dry place in its original packaging, protected from dust and dirt until it is installed in its final location. Do not accept delivery if the apparatus is not in its original packaging or shows clear signs of having been manipulated in any way.
3. Do not place heavy weights on the packed product and avoid knocking or dropping it.
4. When handling heavy products, adequate lifting equipment should be used to avoid harming people or damaging the product itself.
5. Never lift a product by pulling it by the wires or terminal/control enclosure.

GENERAL

6. The K154 DIGITAL INVERTER VFD range comprises of single-phase (1PH) in, three-phase out (3PH) Variable Frequency Inverters specifically intended to control Kruger 3PH-220V fans,

Specification

7. The single-phase input Inverter control is designed for continuous operation with the maximum rated current load, (4.5 to 16A, depending on version) on single phase 230 Volts ~ 50Hz supply.
8. The normal equipment temperature range is -10°C to +40°C.
9. The normal equipment humidity range is 20% RH to 90% RH.

10. The Inverter is not suitable for positioning where corrosive gas, oil, mist etc. are present.
11. The unit meets the EMC requirements of EN 61000-3-3:2015 and EN 61000-3-2:2015
12. The control is housed in an enclosure that is suitable for the current rating and is IP54 rated.

Modes of Operation for the Packaged INVERTER/FAN Range

13. There are 3 modes of fan operation via the Inverter detailed:-
 - a. Off/On to installer-defined speed and thereafter manual speed adjustment via the Inverter's integral keypad. (1PH>3PH - Wiring Diagram No.1)
 - b. Off/On and speed control by accessory REB-ECOWATT 0-10V Speed Controller. (Wiring Diagram No.1 PLUS additional Wiring Diagram No.2).
 - c. Off/On to installer-defined speed via a Remote (wired) OFF/ON Volt-free Switch. (Wiring Diagram No.1 PLUS additional Wiring Diagram No.3).

Keypad




Fig. 1 Operation Pad Diagram

14. Using the Keypad

a. Navigation of the keypad is via the arrow keys.

- i. To move to the left digit, press ◀
- ii. To move to the right digit, press ▶
- iii. To increase the value of a digit, press ▲
- iv. To decrease the value of a digit, press ▼

Important Information for the Safety of Installers and Users

15. Installation must only be carried out by qualified persons.

16. Make sure that the installation complies with each country's current mechanical and electrical norms.

17. Once ready to use, the apparatus must fulfil the following standards:

- a. Standard for Low Voltage Installations 2006/95/CE
- b. Machinery Standard 2006/42/CE
- c. Standard for Electromagnetic Compatibility 2004/108/CE

18. Any area in or around a machine, where the presence of people can cause situations of danger for their safety or health, can be considered a high risk area.

19. This apparatus must not be used in explosive or corrosive atmospheres.

20. If an Inverter is required for working in the previously stated conditions, consult the Kruger Technical Department.
21. If the apparatus is going to be used in atmospheres with over 90% relative humidity, consult the Kruger Technical Department first.

Safety During Installation

22. When installing the Inverter, make sure that all the fittings are in place and that the structure which supports it is resistant enough to bear its weight at full functioning power.
23. Before manipulating the apparatus, make sure the mains supply is disconnected, even if the Inverter is switched off.
24. Check that the mains supply voltage and frequency values coincide with the stipulations on the characteristics plate.
25. Follow the connections diagram(s) for the electrical connections.
26. An earth connection is necessary, check that it is correctly connected and that adequate thermal and overloading protection has been connected and adjusted to the corresponding limits – please refer to note #37 below.

Mechanical Installation

27. The Inverter is intended to be supplied ONLY with a corresponding Kruger 3PH 230V ventilation fan. Check that the size and the speed of the fan can be safely controlled by this Inverter.
28. Install the Inverter in a dry sheltered position.
29. Leave an air space of not less than 150mm around the controller to allow cooling air to flow freely. Leave an additional gap in front of the Inverter to allow for access during installation/wiring/maintenance. Do not install in close proximity to other heat sources. The maximum ambient temperature for the controller must not exceed 40°C. The maximum humidity for the controller must not exceed 90%R.H.
30. The product should be vertically mounted only. In this orientation it is suitable for fitment onto a suitable supportive structure and secured through the 4 fixing holes provided.

Electrical Installation of the Inverter to an Appropriately Sized Kruger Fan

WARNING!

31. Mains voltage is present. It is the responsibility of the user to ensure compliance with the Health and Safety at Work.

CAUTION

- 32. Isolate mains supply before connecting.
- 33. This unit must be earthed.
- 34. All electrical connections should be made by a qualified electrician.
- 35. All wiring must be in accordance with current wiring regulations.
- 36. The apparatus should be provided with a separate suitably rated double pole isolator or switch.
- 37. The breaker capacity current and cable sizes for each Inverter type are shown in table 1 below.

Table 1.

Inverter Model	Breaker Capacity Current	Cable Sizes	
		Input Cable	Output Cable
1-PH>3PH 0.75kW 4.5A	20A	2.5mm ²	2.5mm ²
1-PH>3PH 1.5kW 7.0A	20A	2.5mm ²	2.5mm ²
1-PH>3PH 2.2kW 10A	32A	4mm ²	2.5mm ²
1-PH>3PH 3.7kW 16A	32A	4mm ²	2.5mm ²

- 38. The cable between the Inverter and fan should be a screened type.
- 39. The Inverter is suitable as supplied for connection to the fan with up to a 25m long connection cable. Installations in excess of this MAX. 25m CABLE LENGTH distance and up to 50m should be fitted also with an EMC Filter (not supplied – Available as an accessory, see Note #66 for additional information). In the uncommon occurrence that the cable length exceeds 50m, a Choke is also required.

In Summary

- Fan plus Inverter Pack as supplied – MAX. CABLE LENGTH 25m
- Fan plus Inverter Pack + EMC Filter – MAX. CABLE LENGTH 50m
- Fan plus Inverter Pack + EMC Filter + Choke – CABLE LENGTH ABOVE 50m

Wiring Installation

40. THE THREE-PHASE FAN TO WHICH THE INVERTER IS TO BE CONNECTED MUST BE CONFIGURED TO ACCEPT A 230V 3-PH SUPPLY

41. Check that the power supply matches that on the Inverter rating plate.
42. The connections as shown in Wiring Diagram No. 1 of this booklet and if the accessory REB-ECOWATT Controller is being employed, Wiring Diagram No. 2 also, or if a remote (wired) on/off switch is employed, then Wiring Diagram No. 3 in addition to No. 1.
The Inverter incorporates a "Running Status Relay", if an output is required to a remote device then in addition to the power connections, the optional **Error Relay Output** connections shown on Wiring Diagram No.1 should be followed. Please refer to note #51 for additional information.
43. All cable entries provided should be used. Any left unused should be blanked and left in a safe condition.
44. Remove the front panel of the controller from the front cover by removing the panel fixing screws. This provides access to all of the terminals located on the control circuit boards plus the earth cable, the flying end of which is taped to the underside of the panel.

NOTE – We do not recommend removing the front cover, however if it is removed then take great care not to damage the ribbon cable which connects the display to the circuit board which is fixed to the base. The ribbon cable's plug can be temporarily unplugged from the socket. When re-attaching the ribbon cable plug be very aware that the plug and socket must be connected in the correct orientation. Re-position the front cover and replace the fixing screws.

IMPORTANT – RISK OF DAMAGE! ENSURE THAT THE PLUG IS TIGHTLY SECURED TO THE SOCKET!

NOTE – When replacing the front cover, ensure that the seal is correctly positioned.


45. Replace the panel when the wiring connections have been made, ensuring that the seal is correctly positioned.
46. Check that the unit mountings and electrical connections are secure and in accordance with the applicable wiring diagram on page 9 (and if applicable, page 14 or 17 also) of this instruction booklet.
47. For wiring diagrams of other schemes, please contact Kruger.
IF IN DOUBT, ASK!

WIRING DIAGRAM No. 1 (SINGLE PHASE 230V ~ 50Hz MAINS SUPPLY)
Off/On to installer-defined speed and thereafter manual speed adjustment via the Inverter's integral keypad.

L – Supply Live 230V ~ 50Hz
 N – Supply Neutral
 E – Earth

WIRING DIAGRAM No. 1 –

Inverter Terminals



OPTIONAL INVERTER TERMINAL USAGE FOR STATUS SIGNALLING



Running Status Relay Output
 TA-TB when Running
 TA-TC when **Non**-Running
 SEE NOTE #51 FOR ADDITIONAL
 INFORMATION

IMPORTANT NOTE TO INSTALLERS!

THE THREE-PHASE FAN TO WHICH THE INVERTER IS TO BE CONNECTED **MUST** BE
CONFIGURED TO ACCEPT A 3-PH 230V SUPPLY, NOT A 400V SUPPLY.
IF IN DOUBT, ASK!

SETTING-UP OVER-CURRENT PROTECTION (PARAMETER F8.20)

48. The impedance overload protection parameter F8.20 varies depending on the type of fan that the Inverter is being connected to and this parameter **MUST** be installer-configured in order to allow the Inverter to safely control and to provide overload protection to the fan which it is intended to control.

49. To calculate the value of the protection parameter F8.20:-

$$\text{Parameter F8.20 Value} = \frac{\text{FAN FULL LOAD CURRENT} \times 110}{\text{INVERTER CURRENT RATING}}$$

Example

FAN FULL LOAD CURRENT is 4.3A
INVERTER CURRENT RATING is 10A


$$\text{Parameter F8.20 Value} = \frac{\text{FAN FULL LOAD CURRENT} \times 110}{\text{INVERTER CURRENT RATING}}$$

$$\text{Parameter F8.20 Value} = \frac{4.3 \times 110}{10A}$$

$$\text{Parameter F8.20 Value} = 47.3 (\%)$$

The Inverter must ONLY be connected to the corresponding fan which it is intended to control.

50. To set Parameter F8.20 to the tabled parameter:-





51. Running Status Changeover Relay Output – The Relay is factory-set to provide the following logic:-

Continuity between TA-TB – Inverter not providing power to the fan (no-run), either in STOP condition or FAULT condition.


Continuity between TA-TC – Inverter providing power to the fan (run)

Contact Rating – 1A


52. Speed Range Scaling – NOTE that the scale for the VFD frequency output, as the inverter leaves the factory is 20.00 Hz – 50.00 Hz. As a result, during

operation, pressing the   keys will by default control the fan between 40 and 100% duty. If this factory default is not suitable for the application's needs then the range can be modified:-

a. To modify the **minimum** speed:-

- i. Energise the VFD.
- ii. Make sure that the VFD is stopped and that the fan is not running.
- iii. Press MODE and "0.0.0.0." will appear.
- iv. Change "0.0.0.0." to "1.9.5.1." and press OK, "F0" will then appear.
- v. Press OK again and "F0.00" will appear.
- vi. Press the  key until "F0.06" is displayed and press OK.
- vii. Change the value from "20.00" to the desired minimum frequency output. **Please note that this value is the minimum running frequency in Hz** (e.g. if you would like the minimum speed set to 30Hz representing 60% duty, then this parameter needs to be modified to "30.00"). There is a reference table of typical values below, (note c).
- viii. Press OK and "F0.07" will be displayed.
- ix. Press MODE twice which will take you back to the home screen (running speed value).
- x. The minimum speed set-up is now complete.

b. To modify the **maximum** speed:-

- i. Energise the VFD.
- ii. Make sure that the VFD is stopped and that the fan is not running.
- iii. Press MODE and "0.0.0.0." will appear.
- iv. Change "0.0.0.0." to "1.9.5.1." and press OK, "F0" will then appear.
- v. Press OK again and "F0.00" will appear.
- vi. Press the  key until "F0.05" is displayed and press OK.
- vii. Change the value from "50.00" to the desired maximum frequency output. **Please note that this value is the maximum running frequency in Hz** (e.g. if you would like the maximum speed set to 40Hz representing 80% duty, then this parameter needs to be modified to "40.00"). There is a reference table of typical values below, (note c).

- viii. Press OK and "F0.06" will be displayed.
- ix. Press MODE twice which will take you back to the home screen (running speed value).
- x. The maximum speed set-up is now complete.

c. Duty Percentage / Frequency / VFD Display Reference


Duty	Frequency	Display		Duty	Frequency	Display
10%	5 Hz	05.00		60%	30 Hz	30.00
20%	10 Hz	10.00		80%	40 Hz	40.00
40%	20 Hz	20.00		90%	45 Hz	45.00
50%	25 Hz	25.00		100%	50 Hz	50.00

If NEITHER a REB-ECOWATT nor a REMOTE (WIRED) SWITCH is connected to the inverter then go to note 55 on page 18.

However if a REMOTE (WIRED) SWITCH IS connected to the inverter then go to note 54 on page 17.




WIRING DIAGRAM No. 2 – Operation Mode b. Off/On and speed control by additional accessory REB-ECOWATT Speed Controller


NOTE – WIRING DIAGRAM No.2 is IN ADDITION TO WIRING DIAGRAM No.1






In addition to Wiring Diagram No. 1, Wiring Diagram No.2 plus the “Programming the Inverter” sequence on note 53 on page 15 of this instruction booklet must be followed.

53. Programming the Inverter – APPLICABLE ONLY TO OPERATION MODE b. Off/On and speed control by additional accessory REB-ECOWATT Speed Controller

- a. Assigning the REB-ECOWATT to the Inverter
- i. Make sure the dial switch on the REB-ECOWATT is “0” position.
 - ii. Energise the VFD.
 - iii. Press MODE and “0.0.0.0.” will appear.
 - iv. Change “0.0.0.0.” to “1.9.5.1.” and press OK, “F0” will then appear.
 - v. Press OK and “F0.00” will appear.
 - vi. Press the  key until “F0.01” is displayed and press OK.
 - vii. Change the value from “0” to “1” and press OK, “F0.02” will then appear. Press OK.
 - viii. Change the value from “0” to “2” and press OK, “F0.03” will then appear. Press OK.
 - ix. Change the value from “00” to “01” and press OK, “F0.04” will then appear.
 - x. Press MODE twice which will take you back to the home screen (running speed value).
 - xi. The set-up is now complete.
- b. Speed Range Scaling – NOTE that the scale for the VFD frequency output, as the inverter leaves the factory is 20.00 Hz – 50.00 Hz. As a result, rotating the REB-ECOWATT dial between the minimum and maximum end stops will by default control the fan between 40 and 100% duty. If this factory default is not suitable for the applications needs then the range can be modified:-
- i. To modify the **minimum** speed:-
 1. Make sure the dial switch on the REB-ECOWATT is “0” position.
 2. Energise the VFD.
 3. Press MODE and “0.0.0.0.” will appear.
 4. Change “0.0.0.0.” to “1.9.5.1.” and press OK, “F0” will then appear.
 5. Press the  key until “F5” is displayed. Press OK and “F5.00” will appear.
 6. Press the  key until “F5.12” is displayed and press OK.

7. Change the value from "040.0" to the desired minimum frequency output. **Please note that this value is a percentage of 50 Hz** (e.g. if you would like the minimum speed set to 30Hz representing 60% duty, then this parameter needs to be modified to "060.0"). There is a reference table of typical values below, (note iii).
8. Press OK and "F5.13" will be displayed.
9. Press the  key until "F5.00" is displayed.
10. Press MODE twice which will take you back to the home screen (running speed value).
11. The minimum speed set-up is now complete.

ii. To modify the **maximum** speed:-


1. Make sure the dial switch on the REB-ECOWATT is "0" position.
2. Energise the VFD.
3. Press MODE and "0.0.0.0." will appear.
4. Change "0.0.0.0." to "1.9.5.1." and press OK, "F0" will then appear.
5. Press the  key until "F5" is displayed. Press OK and "F5.00" will appear.
6. Press the  key until "F5.14" is displayed and press OK.
7. Change the value from "100.0" to the desired maximum frequency output. **Please note that this value is a percentage of 50 Hz** (e.g. if you would like the maximum speed set to 45Hz representing 90% duty, then this parameter needs to be modified to "90.00"). There is a reference table of typical values below, (note iii).
8. Press OK and "F5.15" will be displayed.
9. Press the  key until "F5.00" is displayed.
10. Press MODE twice which will take you back to the home screen (running speed value).
11. The maximum speed set-up is now complete.

iii. Duty Percentage / Frequency / VFD Display Reference


Duty	Frequency	Display		Duty	Frequency	Display
10%	5 Hz	010.0		60%	30 Hz	060.0
20%	10 Hz	020.0		80%	40 Hz	080.0
40%	20 Hz	040.0		90%	45 Hz	090.0
50%	25 Hz	050.0		100%	50 Hz	100.0

WIRING DIAGRAM No. 3 – Operation Mode c. Off/On via remote (wired) OFF/ON switch.

NOTE – WIRING DIAGRAM No. 3 IS IN ADDITION TO WIRING DIAGRAM No. 1
In addition to Wiring Diagram No. 1, Wiring Diagram No. 3 plus the “Programming the Inverter” sequence below must be followed.



**54. Programming the Inverter – APPLICABLE ONLY TO OPERATION MODE c.
Off/On by a REMOTE (WIRED) VOLT-FREE ON/OFF SWITCH.**

- a. Make sure the ON/OFF switch is “OFF”.
- b. Energise the VFD.
- c. Press MODE and “0.0.0.0.” will appear.
- d. Change “0.0.0.0.” to “1.9.5.1.” and press OK, “F0” will then appear.
- e. Press OK and “F0.00” will appear.
- f. Press the  key until “F0.01” is displayed and press OK.

- g. Change the value from "0" to "1" and press OK, "F0.02" will then appear.
- h. Press MODE twice which will take you back to the home screen (running speed value).
- i. The set-up is now complete.

55. Pre starting-up checks – before starting up the fan, ensure that:

- a. The apparatus is well secured and that the electrical connections have been carried out correctly.
- b. No loose material or fitting remains can be sucked up by the ventilator. If the ventilator has been mounted in a duct, make sure it is clear of loose material.
- c. The earth fittings are adequately connected.
- d. No electrical continuity exists between phases on the Inverter input side nor output side nor between Live phases and Earth.
- e. The electrical safety devices are correctly connected, adequately adjusted and ready for use.
- f. The Inverter enclosure and electrical cable glands are correctly sealed and water-tight.



56. When starting up the product, ensure that:

- a. The impeller turns in the correct direction. If the impeller rotates in the wrong direction then press the STOP/RESET key immediately.

IF THE IMPELLER ROTATES IN THE WRONG DIRECTION THEN THE INVERTER/FAN MUST BE ISOLATED FROM THE MAINS SUPPLY AND ANY 2 PHASES BETWEEN THE INVERTER AND FAN THEN REVERSED BEFORE RE-STARTING.

- b. There are no abnormal vibrations.
- c. If any of the electrical safety devices blow, the apparatus must be quickly disconnected from the mains supply.
- d. The whole installation should be carefully checked before trying to start-up the fan again.

57. If the **inverter keypad is being used for control**, then switch on the control by pressing the "RUN" Key. The fan will start.

- a. The Inverter has been factory set to accelerate the fan speed to 100% (50Hz) Inverter output in 40 seconds. The Inverter display will show the climbing frequency output from 0 to 50Hz over a 40 second period of time. When the fan has reached its maximum speed the frequency count on the display will stop counting at 50.00. NOTE that if this factory-set maximum speed has been modified as per note #53b, then the inverter will accelerate to, and display the modified set value.
- b. When running, adjust the frequency output with the   keys until the required fan duty point has been reached. Holding the keys down will speed-up the frequency change. For a more accurate frequency change (to fine-tune the Inverter output/fan speed), press and release the keys quickly rather than holding them down.
- c. To stop the fan, press the STOP/RESET key. The fan will decelerate over a period of 40 seconds until it stops.
- d. When "RUN" is pressed again to re-start the fan, the fan will accelerate to the speed defined by the frequency output previously set (in #57b, above). When the fan has reached the speed, the frequency count on the display will stop counting at the previously defined duty point frequency output (in #57b, above).



Or,

58. If an **REB-ECOWATT Controller is connected**, then rotate the REB-ECOWATT dial clockwise (CW) to its maximum. The fan will start.



- a. The Inverter has been factory set to accelerate the fan speed to 100% (50Hz) Inverter output in 40 seconds. The Inverter display will show the climbing frequency output from 0 to 50Hz over a 40 second period of time. When the fan has reached its maximum speed the frequency count on the display will stop counting at 50.00. NOTE that if this factory-set range has been modified as per note 53b.ii, then the inverter will accelerate to, and display the modified set value.
- b. When running, adjust the frequency output with the REB-ECOWATT dial until the required fan duty point has been reached.
- c. To stop the fan, dial counterclockwise (CCW) of REB-ECOWATT to "0" position. The fan will decelerate over a period of 40 seconds until it stops.
- d. When the the REB-ECOWATT dial clockwise (CW) to its maximum again to re-start the fan, the fan will accelerate to the speed defined by the frequency output previously set (in #58b, above). When the fan has reached the speed the frequency count on the display will stop counting at the previously defined duty point frequency output (in #58b, above).

Or,

59. If a **Remote (wired) Switch is connected** then change the switch to the “On” position. The fan will start.

- a. The Inverter has been factory set to accelerate the fan speed to 100% (50Hz) Inverter output in 40 seconds. The Inverter display will show the climbing frequency output from 0 to 50Hz over a 40 second period of time. When the fan has reached its maximum speed the frequency count on the display will stop counting at 50.00. NOTE that if this factory-set maximum speed has been modified as per note 53b, then the inverter will accelerate to, and display the modified set value.
- b. When running, adjust the frequency output with the   keys until the required fan duty point has been reached. Holding the keys down will speed-up the frequency change. For a more accurate frequency change (to fine-tune the Inverter output/fan speed), press and release the keys quickly rather than holding them down.
- c. To stop the fan, change the switch to the “Off” position. The fan will decelerate over a period of 40 seconds until it stops.
- d. When the switch is changed to the “On” position again to re-start the fan, the fan will accelerate to the speed defined by the frequency output previously set (in #59b, above). When the fan has reached the speed, the frequency count on the display will stop counting at the previously defined duty point frequency output (in #59b, above).

Operating Instructions

60. If the **inverter keypad is being used for control** then switch on the control by pressing the "RUN" Key. The fan will start.
- The Inverter display will show the climbing frequency output from 0 to the defined duty point frequency. When the fan has reached its set speed the frequency count on the display will stop counting at the corresponding frequency output value.
 - When running, the frequency output can be adjusted within the 40% - 100% duty range (or, if this factory-set range has been modified as per note #53) with the   keys until the required fan speed is been reached. Holding the keys down will speed-up the frequency change. For a more accurate frequency change (to fine-tune the Inverter output/fan speed), press and release the keys quickly rather than holding them down.
 - To stop the fan, press the STOP/RESET key. The fan will stop.

Or,

61. If an **REB-ECOWATT Controller is connected** then rotate the REB-ECOWATT dial clockwise (CW) to its maximum. The fan will start.
- The Inverter display will show the climbing frequency output from 0 to the defined duty point frequency. When the fan has reached the speed corresponding to the REB-ECOWATT dial position, the frequency count on the display will stop counting at the corresponding frequency output value.
 - When running, if required, the frequency output can be adjusted with the REB-ECOWATT dial until the required fan duty point has been reached.
 - To stop the fan, dial counterclockwise (CCW) of REB-ECOWATT to "0" position. The fan will decelerate over a period of 40 seconds until it stops.

Or,

62. If a **Remote (wired) Switch is connected** then change the switch to the "On" position. The fan will start.
- The Inverter display will show the climbing frequency output from 0 to the defined duty point frequency. When the fan has reached the duty point speed, the frequency count on the display will stop counting at the corresponding frequency output value.
 - To stop the fan, change the switch to the "Off" position. The fan will decelerate over a period of 40 seconds until it stops.

63. If a fan failure is detected by current overload then the Inverter will shut down the fan. If this occurs then "OL3" will be displayed.

Troubleshooting

64. If after the fan has been running for some time there is a fault condition, then the reason for the fault needs investigation/correction prior re-energisation.

65. Fault code table

Fault Code	Fault Type	Reason	Solution
OL3	Overload Alarm	<ol style="list-style-type: none"> 1. The motor is running backwards. 2. The pressure in the system is too high. 3. The airflow temperature has exceeded the maximum temperature of the fan rating plate. 	<ol style="list-style-type: none"> 1. Swap any two of the output phase on U, V or W. 2. Speak to Kuger for advice. 3. Speak to Kruger for advice.
Lu	Under Voltage When Running	<ol style="list-style-type: none"> 1. The input voltage is too low. 2. Sudden power loss. 3. Input power fault. 4. Poor contact of the DC circuit. 5. Contactor with poor contact. 	<ol style="list-style-type: none"> 1. Check the input voltage. 2. Reset the inverter and check the input power. 3. Check the input power of the grid. 4. Check the main circuit or ask for service. 5. Check the contactor or ask for service.
LP	Input Phase Loss	<ol style="list-style-type: none"> 1. R, S and T phase loss. 	<ol style="list-style-type: none"> 1. Check the input voltage. 2. Check installation distribution.
SPO	Output Phase Loss	<ol style="list-style-type: none"> 1. U, V and W phase loss or serious asymmetrical three phase of the load. 	<ol style="list-style-type: none"> 1. Check installation distribution. 2. Check the motor 3. Cable between the fan and inverter.
OH1	Inverter Overheat	<ol style="list-style-type: none"> 1. Ambient temperature is too high. 2. The Inverter cooling fan is damaged. 3. The Inverter cooling channels on the heatsink are either blocked or obstructed. 	<ol style="list-style-type: none"> 1. Lower the ambient temperature. 2. Replace the inverter cooling fan. 3. If the heatsink is blocked then remove the blockage. If the heatsink is obstructed then remove the obstruction or relocate the inverter.

EMC Filters

66. As noted #39, the Inverter is suitable as supplied for connection to the fan with up to a 25m long connection cable. Installations in excess of this MAX. 25m CABLE LENGTH distance and up to 50m should be fitted also with an EMC Filter (not supplied however available as an accessory) between the mains supply and the Inverter. In the uncommon occurrence that the cable length exceeds 50m, a Choke is also required.

Suitable for Inverter	Input Filter model	Output Filter model
K154-0R7G-2 (1-PH, 4.5A)	BK-10A--H0.2	BKL-5A-H0.2
K154-1R5G-2 (1-PH, 7.0A)		BKL-10A-H0.2
K154-2R2G-2 (1-PH, 10A)		
K154-3R7G-2 (1-PH, 16A)	BK-20A--H0.2	BKL-20A-H0.2

Recycling

67. EEC Standards, together with the responsibility we should assume with future generations in mind, oblige us to recycle all the materials we can. Therefore, please deposit all left-over material and packaging in their corresponding recycling containers and hand in the replaced machines to the nearest handler of this type of waste product.

68. If you have any queries about Kruger products, please contact our after-sales service at your local Kruger office. If in doubt, please visit our website at www.krugerfan.com

EC DECLARATION OF CONFORMITY

Herewith we declare that the fan/control designated below, on the basis of its design and construction in the form brought onto the market by us is, in accordance with the relevant EC Council Directives on Electromagnetic Compatibility. If alterations are made to the apparatus without prior consultations with us, this declaration becomes invalid. We further declare that the equipment identified below may be intended to be assembled with other equipment/machines to constitute machinery, which shall not be put into service until the assembled machinery has been declared in conformity with the provisions of these relevant EC Council Directives.

DESIGNATION OF EQUIPMENT

Relevant EC Council Directives, Electromagnetic Compatibility Directive 2014/30/EU

GUARANTEE

Kruger Limited Warranty 24 (TWENTY FOUR) MONTH PRODUCT WARRANTY

Kruger Limited warrants that the K154 DIGITAL INVERTER will be free from defective materials and workmanship for the period of 24 (twenty four) months from the date of original purchase. In the event that we find any part is defective the product will be repaired or at the company's discretion, replaced without charge provided that the product has been installed in accordance with the enclosed instructions and all applicable standards and national and local building standards.

IF CLAIMING UNDER WARRANTY

Please return the completed product, carriage paid, to your local authorized distributor. All returns must be accompanied by a valid Invoice of Sale. All returns must be clearly marked "Warranty Claim", with an accompanying description stating the nature of the fault.

THE FOLLOWING WARRANTIES DO NOT APPLY

Damages resulting from improper wiring or installation.
Damages resulting when using the fan/control with fans/motors/controls/sensors other than those supplied and manufactured by the Kruger Group of Companies.
Removal or alteration of the Kruger data plate label.

WARRANTY VALIDATION

The end user must keep a copy of the Invoice of Sale to verify a purchase date.

KRUGER Ventilation Group

THAILAND (Regional HQ)

KRUGER VENTILATION INDUSTRIES ASIA CO. LTD.
30/159 Moo 1, Sinsakorn Industrial Estate,
Chetsadawithi Road, Khok Kham Mueng, Samuthsakorn 74000, Thailand
Tel: +662 1054298 Fax: +662 0248256-9
Website: www.krugerfan.com

THAILAND

KRUGER VENTILATION IND. (THAILAND) CO. LTD.
30/105 Moo 1, Sinsakorn Industrial Estate,
Chetsadawithi Road, Khok Kham Mueng, Samuthsakorn 74000, Thailand
Tel: +662 1050399 Fax: +662 1050370-2
Email: mktg@kruger.co.th

INDIA

KRUGER VENTILATION INDUSTRIES (INDIA) PVT. LTD.
Kruger Centre, Mumbai-Nasik Highway,
Kalamgaon, Shahapur, Thane 421601, Maharashtra, India
Tel: +91 9960558899/9975577211
Email: sales@krugerindia.com

INDIA (NORTH)

KRUGER VENTILATION INDUSTRIES (NORTH INDIA) PVT LTD
Village Rohad, Tehsil Bahadurgarh, Jhajjar, Haryana-124507
Tel: +91-9958991652/9958991660/8586966303
Fax +91-1276-278096
Email: sales.kni@krugerindia.com , service@krugerindia.com

KOREA

NEOMATE CO. LTD.
2-1010, Ace High Tech City B/D, 775 Gyeongin-ro,
Yeongdeungpo-gu, Seoul, Korea. Postal Code 07299
Tel: +82-2-2679-2052 Fax: +82-2-2679-2174
Email: y7890@neomate.co.kr

MYANMAR

KRUGER VENTILATION (MYANMAR) CO. LTD.
Room No. F21, Thiri Yadanar Whole Sale Market, (Htawunbe)
Toe Chae Ward, North Okkalapa Township, Yangon.
Tel: +959 763141081/2/3
Email: htoon@krugermm.com

SINGAPORE

KRUGER ENGINEERING PTE. LTD.
2 Venture Drive #20-23, Vision Exchange,
Singapore 608526.
Tel: +65 68631191 Fax: +65 68631151
Email: mktg@krugerfan.com

AUSTRALIA

S&P KRUGER AUSTRALIA PTY. LTD.
2 Cunningham St, Moorebank N.S.W. 2170
Tel: +61 2-98227747
Fax: +61 2-98227757
Email: info@sandpkruger.com.au

DUBAI

KRUGER VENTILATION INDUSTRIES, GULF BRANCH.
Jebel Ali Free Zone Authority (JAFZA) P.O. Box No. 262949, Dubai,
UAE
Tel: +971 4 8819188/8832017
Fax: +971 4 8832018
Email: jsereno@krugerfan.com

INDONESIA

P.T. KRUGER VENTILATION INDONESIA.
JL. Teuku Umar No.20,
Karawaci - Tangerang 15115, Indonesia
Tel: +62 21-5512288/5513557 Fax: +62 21-5513502
Email: mktg@krugerindo.co.id

CHINA (GUANGZHOU)

GUANGZHOU KRUGER VENTILATION CO. LTD.
No. 9 Huahui Road, Huashan, Huadu,
Guangzhou, P.R. China 510880
Tel: +86 20-66356635 Fax: +86 20-86786001/86786500
Email: gzkru@krugergz.com

CHINA (TIANJIN)

TIANJIN KRUGER VENTILATION CO. LTD.
Jingjin Science and Technology Park
Wuqing District, Tianjin, China
Tel: +86 22-22143480/3481 Fax: +86 22-22143482
Email: krugertj@krugertj.com

CHINA (SHANGHAI)

Shanghai Kruger Ventilation Co., Ltd.
No.500 Yuanguo Road, Anting, Jiading District,
Shanghai 201814, P.R. China
Tel: +86 21-69573266 Fax: +86 21-69573296
Email: shkru@krugerchina.com

CHINA (WUHAN)

WUHAN KRUGER VENTILATION CO. LTD.
No. 805, Huian Ave, Dongxihu District, Wuhan, Hubei, P.R. China 430040
Tel: +86 27- 83248840/83060522/83097505
Fax: +86 27- 83261886
Email: whkru@krugerwh.com

HONG KONG

KRUGER VENTILATION (HONG KONG) LIMITED.
Flat C, 9/F, Yeung Yiu Chung (No.8) Industrial Building, 20
Wang Hoi Road, Kowloon Bay, Kowloon, Hong Kong
Tel: +852 22469182 Fax: +852 22469187
Email: info@kruger.com.hk

TAIPEI

KRUGER VENTILATION (TAIWAN) CO. LTD.
No. 157, Ping-an Rd, Hengfeng Village,
Dayuan Shiang Taoyuan County 337, Taiwan
Tel: +886 3-3859119 Fax: +886 3-3859118
Email: sales@krugertwn.com.tw

MALAYSIA

KRUVENT INDUSTRIES (M) SDN. BHD.
Lot 850, Jalan Subang 7, Taman Perindustrian Subang, 47500,
Subang Jaya, Selangor D.E.
Tel: +603 80743399 Fax: +603 80743388
Email: mktg@kruger.com.my

PHILIPPINES

KRUGER M & E INDUSTRIES CORPORATION
B3 Welborne Industrial Park
Bancal Carmona Cavite 4116, Philippines
Tel: +63-2-7 6223260 * +63-46 4129652
HP: +63 925 8018444
Email: mktg@krugerph.net

VIETNAM

KRUGER VENTILATION INDUSTRIES (VIETNAM) CO. LTD.
Lot A7. 2-4, C2 Road, Thanh Thanh Cong IZ,
Trang Bang Dist. Tay Ninh Province, Vietnam
Tel: +84-276 3585200/01/02 Fax: +84-276 3585199
Email: mktg@krugervn.com



Kruger Ventilation Industries Asia Co., Ltd.

30/159 Moo 1, Sinsakorn Industrial Estate Chetsadawithi
Road, Khok Kham Mueng, Samuthsakorn 74000, Thailand

Tel: +662 1054298 Fax: +662 0248256-9

Tel: +662 1054298 Fax: +662 0248256-9

Website: www.krugerfan.com

A member of



Edition 1

Printed in August 2021