



# ***General Instructions*** ***(Propeller Fan)*** **APL-APN Series**



This manual is to assist the engineer to avoid the most common fan problems caused by improper storage, installation, operation and maintenance. **HANDLING AND MAINTENANCE SHOULD ALWAYS BE PERFORMED BY EXPERIENCED AND TRAINED PERSONNEL.**

## **RECEIVING, HANDLING AND STORAGE**

Rough handling during shipment and improper storage can cause damage that is not noticeable until the fan is in operation. This can be avoided with proper storage and handling techniques.

Fan should be hoisted with slings placed around the fan housing. Touch up the scratch coated surfaces during lifting, to prevent corrosion to occur at this area. Store the fan in a clean and dry place, preferably indoor to ensure fan shaft, bearing and fan casing are protected against dust and corrosion. Do not store the fan in a location where it will be subjected to vibration. This can cause the internal surface to rub against each other and damage the bearings.

## **START-UP CHECK LIST**

Before putting any fan into initial operation the manufacturer's instruction must be followed. Complete the following checklist to make sure that the fan is ready to run.

Lock out the primary and all secondary power sources.

Ensure that all fastener, particularly impeller fastener, are tight prior to start-up. Do not re-use locking fasteners.

Regularly check impeller fastener for tightness.

Spin impeller to see whether it rotates freely and is not grossly out of balance.

Inspect impeller for correct rotation for the fan design.

Properly secure all safety guards.

Switch on the electrical supply and allow the fan to reach full speed.

Check carefully for :- (1) Excessive vibration  
(2) Unusual noise  
(3) Proper amperage and voltage values

If any problem is indicated, SWITCH OFF IMMEDIATELY. Lock out the electrical supply, secure the fan impeller if there is a potential for wind milling. (impeller turning due to a draft through the system).

Check carefully for the cause of the trouble and correct as necessary.

The fan may now be put into operation but during the first 8 hrs of running, it should be periodically observed and checked for excessive vibration and noise. Checks should be made of motor input current and motor & bearing temperature to ensure that they do not exceed manufacturer's recommendation. After 8 hrs of operation, the fan should be shut down to check the following items :-

- (1) All set screws and hold-down bolts
- (2) Bearing housing temperature

## INSTALLATION

- X Ensure that suitable fastener is used for each of the mounting holes in the panel.
- X Ensure that the fan panel and drive components are not bent or twisted during installation.
- X Fan should be installed so that any obstructions will not be within 1 Diameter of the fan inlet and outlet.
- X Ensure that the fan orientation is correct for the required air flow direction.

### Electrical Connection

Before carrying out any installation or wiring of the range ensure that the mains electrical supply is disconnected.

Before making any electrical connections ensure that the voltage and frequency of the mains electrical supply matches that of the fan data plate label (maximum permissible deviation of voltage and frequency +/- 5%).

All models must be wired in accordance with the enclosed instructions and the direction of rotation must be checked.

The earth connection must be connected and checked for continuity before leaving the installation.

In addition it is important to check that the wires within the terminal block/box are separated whereby a minimum of 10mm distance (at 400 volts) and that the wires are correctly and firmly tightened within the terminal block and that the connection box lid is required.

### Impeller (For APN only)

All APN fans include a dynamically balanced impeller. The impellers with adjustable pitch angle have been factory set to the correct blade angle of operation. **UNDER NO CIRCUMSTANCES MUST THE BLADE ANGLE BE ADJUSTED OR CHANGED, OTHER THAN BY AN KRUGER APPROVED ENGINEER.**

### ROUTINE MAINTENANCE

Maintenance should always be performed by experienced and trained personnel. Do not attempt any maintenance on a fan unless the electrical supply has been locked out or tagged out and the impeller has been secured.

Under normal circumstances, handling clean air, the system should require cleaning only about a year. However, the fan and system should be checked at regular intervals to detect any unusual accumulation.

The fan impeller should be specially checked for build-up of material or dirt which may cause an imbalance with resulting undue wear on bearings and belt drives. A regular maintenance program should be established as needed to prevent material build-up.

Periodic inspection of the rotating assembly must be made to detect any indication of weakening of the rotor because of corrosion, erosion, or metal fatigue.

# KRUGER GROUP (VENTILATION)

## • THAILAND (Regional HQ)

**KRUGER VENTILATION INDUSTRIES ASIA CO. LTD.**  
30/159 Moo 1, Sinsakorn Industrial Estate,  
Chetsadawithi Road, Khok Kham Mueng, Samuthsakorn 74000, Thailand  
Tel. +662 1054298 - Fax +662 0248256-9  
Website: www.krugerfan.com

## • CHINA (BEIJING)

**BEIJING KRUGER VENTILATION CO. LTD**  
Level 7, A Block, Rising International Building, 29 JingHai San Road, BDA,  
Beijing, P.R.China 100176  
Tel. +86 10-67881366 - Fax +86 10-67880566  
Email: krugertj@krugertj.com

## • CHINA (SHANGHAI)

**SHANGHAI KRUGER VENTILATION CO. LTD**  
No. 500 Yuanguo Road, Anting, Jiading,  
Shanghai 201814 P.R. China  
Tel. +86 21-69573266 - Fax +86 21-69573296  
Email: shkruger@krugerchina.com

## • CHINA (WUHAN)

**WUHAN KRUGER VENTILATION CO. LTD**  
No. 805, Huian Ave, Dongxihu District, Wuhan, Hubei, P.R. China 430000  
Tel. +86 27- 83248840/83060522/83097505  
Fax +86 27- 83261886  
Email: whkruger@krugerwh.com

## • HONG KONG

**KRUGER VENTILATION (HONG KONG) LIMITED**  
Flat C, 9/F, Yeung Yiu Chung (No.8) Industrial Building,  
20 Wang Hoi Road, Kowloon Bay, Kowloon, Hong Kong  
Tel. +852 22469182 - Fax +852 22469187  
Email: info@kruger.com.hk

## • INDIA (NORTH)

**KRUGER VENTILATION INDUSTRIES (NORTH INDIA) PVT LTD**  
Plot No. - 191, Sector - 59, Ballabgarh, Faridabad - 121 004, Haryana, India  
Tel. +91-9958991660/9717449696  
Fax. +91-1294135820  
Email: sales.kni@krugerindia.com

## • KOREA

**NEOMATE CO. LTD**  
2-1010, Ace High Tech City B/D, 775 Gyeongin-ro,  
Yeongdeungpo-gu, Seoul, Korea. Postal Code 07299  
Tel. +82-2-2679-2052 - Fax. +82-2-2679-2174  
Email: y7890@neomate.co.kr

## • MYANMAR

**KRUGER VENTILATION (MYANMAR) CO.LTD**  
Room No. F21, Thiri Yadanar Whole Sale Market, (Htawunbe)  
Toe Chae Ward, North Okkalapa Township, Yangon.  
Tel. +959 763141081/2/3  
Email: htoon@krugermm.com

## • SINGAPORE

**KRUGER ENGINEERING PTE LTD**  
No. 10 Buroh Street #06-06, West Connect Building,  
Singapore 627564  
Tel. +65 68631191 - Fax +65 68631151  
Email: mktg@krugerasia.com

## • THAILAND

**KRUGER VENTILATION IND. (THAILAND) CO. LTD**  
30/105 Moo 1, Sinsakorn Industrial Estate,  
Chetsadawithi Road, Khok Kham Mueng, Samuthsakorn 74000, Thailand  
Tel. +662 1050399 - Fax + 662 1050370-2  
Email: mktg@kruger.co.th

## • AUSTRALIA

**S&P-KRUGER AUSTRALIA PTY LTD**  
2 Cunningham St, Moorebank N.S.W. 2170  
Tel. +61 2-98227747  
Fax. +61 2-98227757  
Email: info@sandpkruger.com.au

## • CHINA (GUANGZHOU)

**GUANGZHOU KRUGER VENTILATION CO. LTD**  
No. 9 Huahui Road, Huashan, Huadu,  
Guangzhou, P.R. China 510880  
Tel. +86 20-66356635 - Fax +86 20-86786001/86786500  
Email: gzkruger@krugergz.com

## • CHINA (TIANJIN)

**TIANJIN KRUGER VENTILATION CO. LTD**  
No.168 Anyuan Road, Jingjin Science and Technology Park  
Wuqing District, Tianjin, China  
Tel. +86 22-22143480/3481 - Fax +86 22-22143482  
Email: krugertj@krugertj.com

## • DUBAI

**KRUGER VENTILATION INDUSTRIES, GULF BRANCH**  
Jebel Ali Free Zone Area (JAFZA) P.O. Box No. 262949, Dubai, UAE  
Tel. +971 4 8819188/8832017  
Fax. +971 4 8832018  
Email: johncs@krugerasia.com

## • INDIA

**KRUGER VENTILATION INDUSTRIES (INDIA) PVT LTD**  
Kruger Centre, Mumbai-Nasik Highway,  
Kalamgaon, Shahapur, Thane 421601, Maharashtra, India  
Tel. +91 9960558899/9975577211 - Fax +91 2527 240075  
Email: sales@krugerindia.com

## • INDONESIA

**P.T. KRUGER VENTILATION INDONESIA**  
Jl. Teuku Umar No.20,  
Karawaci - Tangerang 15115, Indonesia  
Tel. +62 21-5512288/5513557 - Fax +62 21-5513502  
Email: mktg@krugerindo.co.id

## • MALAYSIA

**KRUVENT INDUSTRIES (M) SDN BHD**  
Lot 850, Jalan Subang 7, Taman Perindustrian Subang,  
47500, Subang Jaya, Selangor D.E.  
Tel. +603 80743399 - Fax +603 80743388  
Email: mktg@kruger.com.my

## • PHILIPPINES

**KRUGER M&E INDUSTRIES CORPORATION**  
FAPI Compound, E. Rodriguez Ave.  
Tunasan, Muntinlupa City 1773, Philippines  
Tel. +63 2-8622892/4/6/7, 5534059 - Fax +63 2-8622891  
Email: mktg@krugerph.net

## • TAIPEI

**KRUGER VENTILATION (TAIWAN) CO. LTD**  
No. 157, Ping-an Rd, Hengfeng Village,  
Dayuan Shiang Taoyuan County 337, Taiwan  
Tel. +886 3-3859119 - Fax +886 3-3859118  
Email: sales@krugertwn.com.tw

## • VIETNAM

**KRUGER VENTILATION INDUSTRIES (VIETNAM) CO. LTD**  
Lot A7. 2-4, C2 Road, Thanh Thanh Cong IZ,  
Trang Bang Dist. Tay Ninh Province, Vietnam  
Tel. +84-276 3585200/01/02 - Fax +84-276 3585199  
Email: mktg@krugervn.com